

Call Forward

Last Modified on 01/26/2018 11:12 am EST


You can set a single call forwarding location for all calls, or set different locations for specific scenarios:

- **Unconditional Forward:** All incoming calls are forwarded immediately. Your handset does not ring first.
- **Busy Forward:** Incoming calls are forwarded when you are busy on another call.
- **No Answer Forward:** Incoming calls are forwarded when they are not answered at your phone.
- **Busy / No Answer Forward:** Incoming calls are forwarded when you are busy on another call or do not answer.


Note that whenever any call forwarding setting is in effect, [Do Not Disturb](#) will be set automatically on your phone.

Your iPECS administrator may have set up call forwarding for you. Any changes you make to call forwarding takes priority over pre-set call forwarding.


Forward your calls



1. Press the right arrow on the multi-directional arrow button. This reveals additional soft-keys. Press the FWD softkey or enter 501 ([feature code](#) to set Call Forward). A flex button can also be programmed as a call forward (see [Assign Phone Feature Buttons](#)).




2. Specify the Forward Type:



- Unconditional Forward: Press **1**.
- Busy Forward: Press **2**.
- No Answer Forward: Press **3**.
- Busy / No Answer Forward: Press **4**.
- Cancel existing forward: **#**.

3. Enter the number where calls will be forwarded. Be sure to specify a dialing prefix and area code as required.



4. If you are setting multiple call forward locations, repeat these steps as needed.
5. Press the **SAVE** softkey. "Regist Success" indicates that the forwarding was successful.
6. Press the speakerphone button to exit the menu.

Cancel call forwarding

There are two options for cancelling the forward.

- Press 502 (feature code to cancel Call Forward). "Delete Success" indicates that canceling the forwarding was successful.
 - Press FWD softkey and enter # as the Forward Type. "Delete Success" indicates that canceling the forwarding was successful. This will cancel the forward. Press the speakerphone button to exit the menu.
-