

# Mute

Last Modified on 01/24/2018 4:51 pm EST

While a call is muted, the other party cannot hear you, but you can hear them.

## Mute the active call

- Press the Mute button. The LED on the Mute button lights up.
- Or, press the MUTE softkey.

## Unmute a call

- Press Mute again.
- Or, press the Speak softkey.