

Group Speed Dial

Last Modified on 01/26/2018 11:15 am EST

Group speed dials are available all members of a group, and are set up by your iPECS administrator. (Your administrator may also create [system speed dials](#) that are available to all iPECS users, and you can create [station speed dials](#) yourself that are local to your phone only.)

Dial a group speed dial

1. Do one of the following:

- Press the group speed dial [programmable feature button](#) , if one is present on your phone.
- Press the DIR softkey and then press 2 for Group Speed.

2. Select a group speed dial:

- Enter the Group Speed Dial number (0000-2999).
- Press the SEARCH softkey to search for a specific speed dial:
 - Toggle the ABC/123 softkey to search using text or numeric characters.
 - Type the first 3 characters of the name by pressing each phone button once. The LCD displays the first close match; you may have to scroll down to find your exact match.

3. Press the SEND softkey to dial the number.