

Auto Dial configuration for LIP phones

Last Modified on 12/24/2025 11:47 am EST

Feature first available:

iPECS Cloud version 8.0.

License Required:

No license required

Description: Auto Dial - Hot / Warm Line

When an extension user goes off-hook, if Auto Dialing Digit is set, it is automatically dialed after the set Auto Dialing Pause Time.

These two settings, Auto Dialing Digit and Auto Dialing Pause Time, are available for LIP terminals.

- If Auto Dialing Pause Time is 0, it works as Hot Line.
 - Immediately dial out to the assigned number.
- If Auto Dialing Pause Time is 5, it works as Warm Line.
 - If there is no input digit during 5 sec., dial out to the assigned number

Programming:

Call Manager>User> User Setup> Device

The screenshot shows the 'User Setup' configuration page for a device. The left sidebar contains a navigation menu with the following items: User (expanded), User Setup (selected), User Phone Configuration, User Feature Configuration, Account Information, Phone Background Image, Call Manager (expanded), Group Settings (expanded), Pickup Group, Paging Group, Hunt Group, Interphone Group, Forward Group, and Auto Attendant. The main configuration area on the right includes the following settings:

Transport Mode	UDP
RTP Security	Follow Company ...
DSS/LSS	Not Used
Differential Ring ID for Internal Call	1
Differential Ring ID for External Call	1
Apply DDI Ringtone	Not Used
Differential Ring	Apply All(Normal, Recall, Forward, Transfer)
Auto Dialing Digit	93002
Auto Dialing Pause Time	0 Sec
Extension Password	*****

The 'Auto Dialing Digit' and 'Auto Dialing Pause Time' fields are highlighted with a red box.